

REMOVAL

1. DISCHARGE REFRIGERANT FROM REFRIGERATION SYSTEM

HINT:

At the time of installation, please refer to the following item.

Evacuate air from refrigeration system.

Charge system with refrigerant and inspect for leakage of refrigerant.

Specified amount: 600 ± 50 g (21.16 ± 1.76 oz.)

2. REMOVE INSTRUMENT PANEL (See page [BO-139](#))

3. REMOVE EXPANSION VALVE

- (a) Pry out the packings.

HINT:

At the time of installation, please refer to the following item.

Do not reuse the packing.

- (b) Using SST, remove the 4 bolts and separate the expansion valve and tube and accessory.

SST 07110-61050

Torque: 4.1 N·m (42 kgf·cm, 36 in.-lbf)

NOTICE:

Cap the open fittings immediately to keep moisture or dirt out of the system.

HINT:

At the time of installation, please refer to the following item.

Lubricate 6 new O-rings with compressor oil and install them to the tube and valve.

