

## INSPECTION

### HINT:

Clean the disassembled parts with compressed air.

- 1. INSPECT CYLINDER BORE FOR RUST OR SCORING**
- 2. INSPECT CYLINDER FOR WEAR OR DAMAGE**

If necessary, clean or replace the cylinder.