


COOLING FAN RELAY INSPECTION

CO1DJ-01

1. INSPECT NO. 1 COOLING FAN RELAY

- (a) Remove the relay box cover.
- (b) Remove the No. 1 cooling fan relay (Marking: FAN NO.1).




- (c) Inspect the resistance.
 - (1) Using an ohmmeter, measure the resistance between the terminals.

Standard:

Tester Connection	Specified Condition
3 - 5	10 kΩ or higher
3 - 5	Below 1 Ω (Apply battery voltage to terminals 1 and 2)


If the resistance is not as specified, replace the relay.

- (d) Reinstall the No. 1 cooling fan relay.
- (e) Reinstall the relay box cover.



2. INSPECT NO. 2 COOLING FAN RELAY

- (a) Remove the relay box cover.
- (b) Remove the No. 2 cooling fan relay (Marking: FAN NO.2).




- (c) Inspect the resistance.
 (1) Using an ohmmeter, measure the resistance between the terminals.

Standard:


Tester Connection	Specified Condition
3 - 4	Below 1 Ω
3 - 4	10 k Ω or higher (Apply battery voltage to terminals 1 and 2)
3 - 5	10 k Ω or higher
3 - 5	Below 1 Ω (Apply battery voltage to terminals 1 and 2)

If the resistance is not as specified, replace the relay.

- (d) Reinstall the No. 2 cooling fan relay.
 (e) Reinstall the relay box cover.

**3. INSPECT NO. 3 COOLING FAN RELAY**

- (a) Remove the relay box cover.
 (b) Remove the No. 3 cooling fan relay (Marking: FAN NO.3).



- (c) Inspect the resistance.
 (1) Using an ohmmeter, measure the resistance between the terminals.

If the resistance is not as specified, replace the relay.

- (d) Reinstall the No. 3 cooling fan relay.
 (e) Reinstall the relay box cover.