


INSPECTION

1. REMOVE ENGINE COVER

Remove the 4 nuts and engine cover.

2. REMOVE VSV




3. INSPECT VSV

(a) Inspect the VSV for open circuit.

Using an ohmmeter, check that there is continuity between the terminals.

Resistance: 27 - 33 Ω at 20°C (68°F)


If there is no continuity, replace the VSV.



(b) Inspect the VSV for ground.


Using an ohmmeter, check that there is no continuity between each terminal and the body.

If there is continuity, replace the VSV.



(c) Inspect the VSV operation.

(1) Check that air does not flow from port E to F.



(2) Apply battery positive voltage across the terminals.

(3) Check that air flows from port E to F.

If operation is not specified, replace the VSV.

4. REINSTALL VSV

5. REINSTALL ENGINE COVER

Install the engine cover with the 4 nuts.