



INSTALLATION

1. INSTALL ROOF DRIP SIDE FINISH MOULDING CLIP

NOTICE:

Only when exchanging the clips.

- (a) Remove the adhesive tape that remains on the moulding surface of the body, and then clean the surface with white gasoline.
- (b) Heat up the moulding and its installation surfaces on the body with a heat light.

Body: 40 - 60°C (104 - 140°F)

Moulding: 20 - 30°C (68 - 86°F)

NOTICE:

Do not heat the moulding excessively.

- (c) Set the supplied clips into the positions as shown in the illustration, and press-fit those clips by hand to install them.
- (d) The installation of the moulding should be carried out 30 minutes or more after press-fitting the clips.

HINT:

- Initial hardening time: 30 minutes
- Perfect hardening time: 24 hours

2. INSTALL MOULDING