

## TROUBLESHOOTING

Problem	Possible cause	Remedy	Page
Engine overheats	Check coolant	Replenish coolant	<a href="#">CO-5</a>
	Water pump drive belt loose or missing	Adjust or replace belt	
	Dirt, leaves or insects on radiator	Clean radiator	
	Hoses, water pump, thermostat housing, radiator, heater, core plugs or head gasket leakage	Repair as necessary	
	Thermostat faulty	Check thermostat	<a href="#">CO-11</a>
	Ignition timing retarded	Set timing	<a href="#">IG-16, IG-19</a>
	Electric cooling system faulty	Inspect electric cooling system	<a href="#">CO-21</a>
	Radiator hose plugged or rotten	Replace hose	
	Water pump faulty	Replace water pump	<a href="#">CO-6</a>
	Radiator plugged or cap faulty	Check radiator	<a href="#">CO-13</a>
Cylinder head or block cracked or plugged	Repair as necessary		

**HINT:** Removal of the thermostat would have an adverse effect, causing a lowering of cooling efficiency. Do not remove the thermostat, even if the engine tends to overheat.