REASSEMBLY

BO0XF-02

The reassembly procedures are the disassembly procedures in reverse order (See page BO-56).

2005 LEXUS IS300 (RM1140U)

Author: Date: 2295