



REMOVAL

REMOVE ROOF DRIP SIDE FINISH MOULDING CENTER

- (a) Tape around the moulding for protection.
- (b) Using a remover for the roof moulding, release both clip engagements in the front end and the rear ends of the moulding, and then remove the roof drip side finish moulding.

NOTICE:

- Do not remove the clips.
- In case that the clips are damaged or removed accidentally, replace them with new ones.