

## INSTALLATION

Installation is in the reverse order of removal (See page [BR-11](#)).

HINT:

- Before installation, adjust length of brake booster push rod (See page [BR-21](#) ).
- After installation, fill the brake reservoir with brake fluid, bleed brake system (See page [BR-4](#) ), and check for leaks.
- Check and adjust brake pedal (See page [BR-6](#) ).