


ENGINE INSPECTION

MA004-19

HINT:

Inspect these items on a cooled down engine.

1. **REPLACE TIMING BELT**
(See page [EM-17](#))
2. **INSPECT DRIVE BELT**
(See page [CH-1](#))
3. **REPLACE SPARK PLUGS**
(See page [IG-1](#))



4. **INSPECT AIR FILTER**

- (a) Remove the air filter.
- (b) Visually check that the air filter is not excessively damaged or oily.

If necessary, replace the air filter.

- (c) Clean the filter with compressed air.
First blow from the inside of the filter thoroughly then repeat from the outside.
- (d) Reinstall the air filter.

5. **REPLACE AIR FILTER**

Replace the air filter with a new one.

6. **REPLACE ENGINE OIL AND OIL FILTER**

(See page [LU-2](#))

7. **REPLACE ENGINE COOLANT**

(See page [CO-2](#))

8. **INSPECT GASKET IN FUEL TANK CAP**

(See page [EC-7](#))

9. **INSPECT FUEL LINES AND CONNECTIONS, FUEL TANK VAPOR VENT SYSTEM HOSES AND FUEL TANK BAND**

Visually check the fuel lines for cracks, leakage, loose connections, deformation or tank band looseness.

10. **INSPECT EXHAUST PIPES AND MOUNTINGS**

Visually check the pipes, hangers and connections for severe corrosion, leaks or damage.

11. **INSPECT VALVE CLEARANCE**

(See page [EM-5](#))