



BRAKE INSPECTION

MA01R-13

1. INSPECT BRAKE LINE PIPES AND HOSES

HINT:

Work in a well-lighted area. Check the entire circumference and length of the brake hoses using a mirror if necessary. Turn the front wheels fully to the right or left before beginning.

- (a) Check all brake lines and hoses for.
 - Damage
 - Wear
 - Deformation
 - Cracks
 - Corrosion
 - Leaks
 - Bends
 - Twists
- (b) Check all the clamps for tightness and connections for leakage.
- (c) Check that the hoses and lines are not near sharp edges, moving parts and the exhaust system.
- (d) Check that the lines are installed pass through the center of the grommets.

2. INSPECT FRONT AND REAR BRAKE PADS AND DISCS

(FRONT PADS: See page [BR-24](#))

(REAR PADS: See page [BR-33](#))

(FRONT DISCS: See page [BR-29](#))

(REAR DISCS: See page [BR-38](#))

3. INSPECT OR CHANGE BRAKE FLUID

(See page [BR-4](#))

Fluid: SAE J1703 or FMVSS No.116 DOT3