




HEATED OXYGEN SENSOR COMPONENTS

SF00B-07



Bank 2 Sensor 1



P

N·m (kgf·cm, ft·lbf) : Specified torque
 ◆ Non-reusable part

43 (438, 31)

B11916

Bank 2 Sensor 2

Heated Oxygen
Sensor Connector

44 (440, 32)

Heated Oxygen Sensor

45 (450, 33)

Pipe Support Bracket

43 (438, 31)

Front Exhaust Pipe
(with Rear TWC)

◆ Gasket

◆ Gasket

43 (438, 31)

N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

P

F20085