

INSTALLATION

HINT:

For step 1 to 4, refer to page [SR-25](#) .

1. **INSTALL SPIRAL CABLE**
2. **INSTALL STEERING COLUMN UPPER AND LOWER COVERS**
3. **INSTALL STEERING WHEEL**
4. **INSTALL STEERING WHEEL PAD**