

# IS F

## OUTLINE OF NEW FEATURES

The following changes have been made for the new IS F.

### 1. Destination Package

The destination package for Australia and New Zealand has been added to models for Europe (USE20R-FEZRHW).

### 2. Interior

- The following interior parts have been changed. For details, [see page 3](#).
  - Front center register
  - Heater control panel
  - Audio head unit
  - Mirror control switch
  - Power window regulator master switch assembly
- One new seat color has been added.

### 3. Power Window System

- The power window regulator motor assembly has been changed which is including power window ECU and Hall IC.
- Variable speed control has been added to the power window system. For details, [see page 6](#).

| Function               | Outline  |
|------------------------|--|
| Variable Speed Control | This control minimizes the occurrence of noise during the power window open/close operation by changing the operating speed of the power window motor. |

### 4. Entry and Start System

A card key is available as optional equipment on models for Australia and New Zealand. Using the card key, the following functions can be performed:

- Door unlock/lock (Entry Unlock/Entry Lock Functions)
- The engine can be started by simply pressing the engine switch while depressing the brake pedal (Start Function)
- The trunk can be opened (Trunk Open Function)

