

■ LIGHT TURN-OFF SYSTEM

The light turn-off system is used to prevent the driver from leaving the vehicle with the headlights, front fog lights, front position lights, taillights, or license plate lights on.

- This system has the following functions:

Function	Outline
Turn-off	When all of the following conditions are met, the headlights or front fog lights turn off. <ul style="list-style-type: none">• The engine switch is changed from on (IG) to off.• The headlight dimmer switch assembly is in the tail or head position.• The headlight dimmer switch assembly (front fog light switch) is on. (Only for front fog lights)
	When all of the following conditions are met, the exterior lights (headlights, front fog lights, front position lights, taillights and license plate lights) turn off. <ul style="list-style-type: none">• The engine switch is changed from on (IG) to off.• The headlight dimmer switch assembly is AUTO.• The headlight dimmer switch assembly (front fog light switch) is on. (Only for front fog light)• The driver door is opened.

► System Diagram ◀

