

REAR WINDOW DEFOGGER SYSTEM

■ DESCRIPTION

The rear window defogger system uses the heater wire on the rear window glass to defog the rear window glass.

- This system is standard equipment on all models.
- The rear window defogger system operates at the same time as the heater function of the outside rear view mirror.
- This system has the following functions:

Function		Outline
Rear Window Defogger Switch-linked Function	Normal Control	Keeps the defogger and mirror heater on for approx. 15 minutes when the rear window defogger switch is on.
	Low Outside Temperature Control	Keeps the defogger and mirror heater on for approx. 60 minutes when the rear window defogger switch is on.
Wiper Switch-linked Function	Wiper Switch ON (INT, AUTO, LO, HI)	Keeps the mirror heater on when the wiper switch is on.
	Wiper Switch Turn OFF	Keep the mirror heater on for approx. 15 minutes after the wiper switch is turn off.