


SEAT HEATER SYSTEM

DESCRIPTION

The seat heater system can steplessly adjust the temperature of the seat surface to between 32_C and 39_C through the operation of a dial-type heater switch.

- A thermistor detects the temperature of the seat surface and the seat heater controller controls it.
- This system is standard equipment on the driver and front passenger seats of all models.



► System Diagram ◀

